

IGLU INUIT WT SCHEME

Air relief valves should be used at the highest point of the system.

