

1. Freeze Protection: 25%- 35% glycol in the system fluid.
2. Air relief valves should be used at the highest point of the system.

IGLU ALEUT WTI HEATING MODE SCHEME

